



## Boot Assembly

P/N B101

- Remove molded handle from our B1000 Brake lever. You may have to use heat for easy removal.
- Install boot over handle and reinstall grip.

### Note:

You may want to put a film of silicone on groove area of lever to secure handle.

